

CUCV Bridge Weight Class Number

From PS Magazine 392 Pg. 40:

CUCV...

## Weight Classes

Your CUCV needs a weight classification so you'll know whether you can cross a bridge when you come to it. Here's the info:

E = Empty			CC = Cross-Country			H = Highway		
LOADED			EMPTY OR LOADED					
TRUCK	E	CC	H	TRUCK WITH TRAILER			CC	H
M1009	2	3	3	M1009 W/M416			3	3
M1008/M1010/ M1028	3	4	4	M1008/1008A1/1031 W/101A1			5	5
M1031	3	5	5	M1028 W/M101A1			6	6

Mount the sign on the left side of the front bumper. NSN 9905-00-565-6267 for the sign kit is on Page 43 of TB 43-0209. ...